MEASURE WINDOW FRAMES CORRECTLY

Only measure the aperture dimension; this is the dimension of the inside of the window frame from one side to the other. Measure according to the instructions below.







First measure your window from left to right.

Start on the left-hand side of the inside of the window frame.

Pull the measuring tape to the right inside of the window frame.

Bend the tape measure into the edge of the frame and read the value.

Now measure your window from top to bottom.

Start at the top on the inside of the window frame.

Pull the measuring tape to the bottom of the window frame.

Bend the tape measure into the edge of the frame and read the value.

At the end of the measuring process, subtract the following dimensions from your result:

4 mm in width 12 mm in height



Width:

- 4 mm =

Height: - 12 mm =